

# Protect your deck



1



## Pre-Installation Protective Oiling

5 Star Timbers will pre-oil your boards with a sealer coat of **FEAST WATSON** **Traditional Timber Oil**. This single coat is designed to seal and protect your timber for a short time during construction. Further coats will be required to fully protect your deck.



2

## Post Installation Weathering

Allow the timber to weather for 4-6 weeks after construction. This is an essential process to enable the release of tannins and oils before any further coats of decking oil are applied.

3

## Top Coat Preparation

Wash your deck with **FEAST WATSON** **WoodClean**. Tannin can harm your deck coating and leave unsightly stains. It is therefore essential to use a specialised timber cleaner to remove any remaining surface contaminants that prevent decking oil from being absorbed evenly into the timber.



4

## Water Bead Testing

Complete a water bead test. Beading indicates there is oil or tannin still present on the surface and they will not accept a water based coating without further washing or weathering.

5

## Top Coat Application

Apply 2-3 coats of your chosen **FEAST WATSON** deck finish. Each recommendation offers a different look. Please refer to all product labels for full directions and ongoing maintenance instructions. All of the premium finishes will weather naturally over time but will not peel, flake or blister.

Decking Oil  
Matte Finish  
Water Wash Up



Wet Look Deck  
Semi Gloss Finish  
Water Wash Up



Traditional Timber Oil  
Matte Finish  
Oil Based, Turps Clean Up



FEAST WATSON APPROVED OILING SYSTEM

For further information please contact:



Stapylton: 07 3386 1055

Woodridge: 07 3386 0595