

Prep Right Traditional Undercoat

D862



Description

A premium quality, dense, easy sanding, solvent based undercoat with excellent surface-filling properties. Prep Right Traditional Undercoat promotes outstanding adhesion over previously painted enamel surfaces.

Uses

Both interior and suitably primed exterior surfaces.

Recommended for

Promote adhesion to "difficult" surfaces.

Technical

Colour Range

White only

Drying And Recoating

Touch dry 4-6 hours. Overcoat after a minimum of 16 hours. at 25°C and 50% relative humidity. Note - Drying time may be lengthened in damp, cold or humid conditions.

Gloss Level

Low Gloss

Odour

Ensure adequate ventilation during use

Specifications met

APAS 0016/1, AS3730.14

Surface Preparation

Remove all loose and flaking paint. Remove surface chalk and powder, dirt, oil, rust and grease. Sand smooth before painting and sand lightly between coats. Surfaces must be clean and dry before painting. Prime bare metal and exterior timber surfaces in accordance with the specification for the surface to be painted as shown on the paint can label. For Example: Exterior timber - PrepRight Wood Primer. Galvanised steel, Aluminium, Zincalume - Taubmans 3 in 1. Steel - PrepRight Iron and Steel Primer.

Aged Enamel

Thoroughly sand with fine paper to remove glossy surface and all flaky pieces

Powdercoated surfaces

Thoroughly sand with fine paper to achieve clean surface free from dust and powder

Application

Application

Apply one coat by brush, roller or spray. A 10mm Democ roller cover or similar will give best results.

Cleanup

Mineral turps

Coverage

Up to 16m²/litre. Coverage will be lower on rough or absorbent surfaces.

Recoat

Recoat after 16 hours at 25°C and 50% relative humidity.

Stirring

Stir paint with a 25mm wide flat stirrer in a circular lifting motion for at least 5 minutes before use. Thin sparingly with mineral turps if necessary.
