

Installation Guide

DeckBone End Matched Joiner

The DeckBone End Matched Joiner is designed to butt join your decking boards OFF or ON the joist.

If the deck board lands on a joist make sure that the screw will be no closer than 10mm from the edge of the joist so the screw can successfully fasten through the DeckBone into the joist. If need be simply choose a different length board. When installing on a joist fasten the Deck Bone with Deck Master Deck Fix 40mm x 8g S/S Screws. Be sure to use a soft clutch setting on your cordless drill.

If the end of the board lands within 35mm from the edge of the joist choose a different length board as the DeckBone will obstruct the TCG Clip installation.

After the board is in position snap the DeckBone in half and insert one half of the DeckBone in the rear section of the end groove. Position the next board in place by sliding the board into the DeckBone. If necessary tap the end of the board you are installing with a rubber mallet to make sure the butt joint is tight. Insert the other half of the DeckBone to complete the butt joint.

Deck Boards 84 - 100mm
Deck Boards 133 - 150mm

Use DeckBone 100
Use DeckBone 150



Please Note:

- Stagger your joints.
- Do Not Join DeckBones Side By Side In The Same Span.
- Use 40mm S.S. Deck Screws when fastening DeckBone to joist.



1/ Insert Rear Half of DeckBone



2/ Insert Next Decking Board



3/ Insert Front Half of DeckBone

For more information please contact Deck Master Pty. Ltd.

E. info@deckmaster.com.au

www.deckmaster.com.au

Ph.1300 939 041

P.O. Box Salisbury, QLD 4107 Australia