

Butt Joining a Starter Board

Joining on a Joist

- If the end of the deck board is positioned on a joist install two Top Fix Starter Clips either side of the raised section of the Weather Strip as shown in diagram 1. Cut two strips of Riser Strip wide enough to cover the underside of the deck boards that are to be installed.



Diagram 1

- Insert the deck boards into the starter clips and then place half of a Deckbone in the other side of the installed deck boards as shown in diagram 2.



Diagram 2

Joining on Blocking or Pole Plate

- If the end of the deck board is positioned over a block or pole plate install Weather Strip on top of the block or pole plate and then fasten two Top Fix Starter Clips either side of the centre of where the deck boards are going to be joined as shown in diagram 3.



Diagram 3

- Insert the deck boards into the starter clips and then place half of a Deckbone in the other side of the installed deck boards as shown in diagram 4.



Diagram 4

www.deckmaster.com.au